

1990 Cruise Pinout (3.0)											
Pin#	ID	Wire Color		Function	Description						
1	TC	L/B		Data Check Connector 1	IH1 Pin14						
2	VP	R/W		Cruise Vacuum Pump	IH1 Pin 2						
3	RV	Y/R		Brake Switch (Y/R)	To Cruise Actuator (Normally Closed)						
4	PL	B/Y		Cruise Light (Combo Meter)							
5	CV	LG		Cruise Actuator							
6	IGB	L/R		To Main Cruise Relay (+12v Switched From Ignition)							
7	O/D	Y/R		Overdrive From ECU (Only on A/T)							
8	SPD	G		Speed Sensor	IH1 Pin 13	From Vehicle Speed Sensor (VSS) From Comb Meter					
9	ECT	R/G		ECT Switch From ECU (Only on A/T)							
10	IGC	L		To Main Cruise Relay							
11	VAC	R		Cruise Vacuum Switch	IH1 Pin 2						
12	B	Y		To Main Cruise Relay (+12v When Main Cruise Switch is ON)							
13	N&C	B/W		Cruise Cluch Cancel Switch							
14	PKB	G/W		Parking Brake Switch	IH1 Pin 2						
15	GND	W/B		Ground	IH1 Pin 2						
16	ACT	B/R		Cruise Actuator							
17	STP-	G/W	E5-24	Brake Switch (G/W)	IH1 Pin 1, Brake Switch (G/W)	Becomes +12v when Brake Pressed					
18	STP+	G/R		Brake Switch (G/R)	To Stop Lights (Normally Open)						
19	CSS	G/Y		Steering Wheel Switches							
20											

